



Convection Oven Full Size

To start the oven attach the propane tank and open the valve. Make sure that the emergency switch is in the on position. Turn the temperature gauge to desired heat. Turn on the fan to either high or low. You will hear a clicking noise will last about 15 seconds. When you hear the clicking stop and the red light is not on, just open the doors and close them to reset the igniter. You will have to do this about 2 or 3 times. Relax, this is normal. You are just bleeding out the air in the system. Once the red light stays on you are heating up. When the light is off means that you are up to temperature.